

# CINCH KIT HINGE OFFSET: HOW TO MEASURE



Measure the distance from the bottom & top of the cabinet to the **MIDDLE** of the bore hole. **Standard is 3" offset.**

**cinchkit**

OPEN THE DOOR TO EASY.